

Installation Guide – Car Windscreen Decals



Please make sure your window is clean and dry then follow the instructions on this 3-minute video:

<https://www.youtube.com/watch?v=6Sh8EJAgNxA&t=1s>

Note: Optimal installation temperature is 15 to 35 degrees Celsius. The adhesive will require more pressure and take longer to take hold in extremely cold temperatures.

Please note the transfer paper is the semi-transparent paper and the backing paper is thicker and whiter.

Tried to keep it as simple as possible with no tools or second person however a second person would help.

If there's two people we'd recommend starting at the left side and placing it down carefully to ensure no bubbles or creases.

It can also be applied wet, however you'll find it much more difficult to remove the transfer paper (especially with the small letters) and may need to let dry for quite a while - even several hours - depending on how wet it is, before removing backing paper, otherwise the letters will just stick to the backing paper and not to the window.

To apply wet - mix a small amount of washing up liquid with water and thoroughly wet the window. Remove backing paper and place the decal and transfer paper on to the window. Adjust position and then use a squeegee to push out all the water from under the letters and allow to dry. A bank card or plastic scraper can be used instead of a squeegee. Then allow to totally dry before removing transfer paper.

Thank you so much for your support. Please upload pics to social media and encourage others to do the same.

Did you know we also have free yard signs available?

Many thanks,
From the team at Farm Transparency Project.